



## WI-127 Indicator User's Manual

#### **UNITED STATES**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### **CANADA**

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la Class A prescrites dans le Reglement sur le brouillage radioelectrique que edicte par le ministere des Communications du Canada.

### **EUROPEAN COUNTRIES**

#### **WARNING**

**This is a Class A product. In a domestic environment this product may cause radio interference in which the user may be required to take adequate measures.**



#### **CAUTION**

**Risk of electrical shock. Do not remove cover. No user serviceable parts inside. Refer servicing to qualified service personnel.**

**Weigh-Tronix reserves the right to change specifications at any time.**

# Table of Contents

Introduction .....	5
Installation .....	5
Operations Mode .....	5
Front Panel .....	6
Keys .....	6
Standard Scale Keys .....	6
Function Keys .....	7
Keypad Keys .....	7
Directional Keys .....	7
Annunciators .....	7
Gross Weighing .....	8
Net Weighing .....	8
Pushbutton Tare .....	8
Quick Keypad Tare Entry .....	9
Selecting a Tare Register .....	9
Entering and/or Changing Values in Tare Registers .....	10
Clearing the Active Tare .....	10
Net Weighing Operation .....	10
Using Cutoff Registers .....	11
Checkweighing .....	12
Setting Target and Over/Under Values .....	12
Checkweighing Operation .....	13
Customizing the Indicator .....	13
Viewing and Editing the ID Number .....	13
Viewing and Setting Time .....	14
Viewing and Setting Date .....	14
Operations Menu .....	15
Serial Communication .....	16
Error Messages .....	16
Indicator Diagnostics .....	17
Test Mode .....	17
In-Motion Option .....	19

**Pages are numbered consecutively beginning with the cover page.**

# WI-127 Specifications\*

## Power requirements:

115 Volts AC, +10% to -15% @ 0.3Amp maximum  
230 Volts AC, +10% to -15% @ 0.15 AMP maximum  
50/60 Hz

## Excitation: 10 Volts DC

Supports up to twelve 350-ohm weight sensors

## Operational keys:

Five yellow standard keys: Zero, Tare, Print, Units, Select  
Three function keys: F1, F2, F3  
Numeric keys: 0-9

## Operational annunciators:

Gross, Tare, Net, Print, Zero, Motion  
Under, Accept, Over, Cutoff, ID,  
Three units of measure

**Display:** Eight digit, seven segment, 0.8-inch high LED

**Display rate:** Selectable (1, 2, 5, 10)

**Analog to digital conversion rate:** 60 times per second

## Unit of measure:

Three, independently programmable:  
Pounds, kilograms, grams, ounces, ton, tonne, custom, Off

## Capacity selections:

999,999 with decimal located from zero to five places

## Incremental selections:

Multiples and sub-multiples of 1, 2, 5

## Programmable selections:

Zero range, motion detection,  
automatic zero tracking, five-point linearization.

## Time and date/RAM:

Battery backed up real time clock and RAM are standard

**Internal resolution:** 6,291,456 counts per mV/V per sec.

## Harmonizer™ digital filtering:

Fully programmable to ignore noise and vibration

## Standard inputs:

Seven configurable logic level inputs for functions such as PB tare, print, zero, units, select, gross and net.

## Standard outputs:

Three outputs, open collector design  
Relay power supply, 24 VDC at 150mA  
Bi-directional serial port (RS-232 or RS-422/485 or 20mA current loop)

## Serial Command Inputs

Programmable serial response to ASCII character input

## Self diagnostics:

Display, keys, inputs, outputs, serial port,  
A to D converter, loadcell output display, voltages

**Circuitry protection:** RFI, EMI, and ESD protection

## Options:

Two additional serial ports  
BCD parallel  
10 cutoffs  
Analog output  
0-5, 0-10 volts  
1-5, 4-20, 10-50 mA

## Operating temperature:

-40 to 140° F (-40 to 60° C)  
100% relative humidity including washdown

**Enclosure:** NEMA 4X stainless steel enclosure

## Dimensions:

12" W x 8" H x 4" D (without mounting bracket)  
12.3" W x 11.0" H x 5.3" D (with mounting bracket)

**Weight:** 12.5 lb, 5.7 kg

## Agencies:

NTEP Class III/IIIL:10,000d, COC #96-140.A1  
Consumer and Corporate Affairs, Canada, #AM-5167  
UL/CUL/CSA  
FCC Class A

\* Specifications subject to change without notice.

# Introduction

The WI-127 is a versatile, full-featured indicator housed in a stainless steel enclosure. Its user interface includes an 8-digit, 7-segment LED display, fourteen LED annunciators, and 24 keys.

This set of instructions is divided into the following sections:

- Introduction
- Installation
- Operations Mode
- Front Panel
- Gross Weighing
- Net Weighing
- Using Cutoff Registers
- Checkweighing
- Customizing the Indicator
- Serial Communication
- Error Messages
- Indicator Diagnostics
- In-Motion Option

# Installation



## Attention

*The socket-outlet must be installed near the equipment and easily accessible.*

Connect the scale interface cable and any other peripheral equipment to the indicator according to the instructions in the Service Manual.

Power up the unit by plugging it into the appropriate AC socket-outlet. See note at left. The unit will power up in operations mode.


# Operations Mode

Operations mode contains all normal weighing operations. In this mode you can view or set the following parameters:

- push-button tare
- quick keypad tare entry
- one to ten tare registers (numbered 1,2,3,4,5,6,7,8,9,0)
- cutoff registers
- target, over and under values
- identification number
- time
- date

# Front Panel

The WI-127's front panel consists of 24 keys and fourteen annunciators.



**Figure 1**  
WI-127 Front Panel

## Keys

### Standard Scale Keys

The WI-127's keys are divided into four primary groups:

**Standard Scale Keys** These yellow keys are common to a majority of weighing applications and include SELECT, TARE, PRINT, ZERO, and UNITS.

- |               |   |
|---------------|---|
| <b>SELECT</b> | Used to switch between the gross, tare, and net display modes. SELECT can also be used to accept a current selection and return to weigh mode from within any menu. |
| <b>TARE</b>   | Enters a pushbutton tare in the display mode. Can be configured to accept values through the numeric keypad.  |
| <b>PRINT</b>  | Used to initiate manual data transmission.  |
| <b>ZERO</b>   | Zeros the scale in the display mode. Also clears values in numeric entry.   |
| <b>UNITS</b>  | Switches the units of measure in the display mode. Up to three units of measure are selectable.   |

## Function Keys

*Operation of these keys changes with the software installed in the WI-127. (standard, in-motion)*

## Keypad Keys

## Directional Keys

**Function Keys** These oval keys along the right side of the display face are configurable and are labeled F1, F2, and F3. The default configurations for these keys are:

- F1**      Accesses tare registers (see page 5)
- F2**      Views and edits ID (see page 9)
- F3**      Accesses cutoff registers (see page 7)

**Keypad Keys** These are the twelve square keys which support numeric entry. The keyboard keys are labelled 0-9, plus/minus (+/-), and decimal point (.) and are located near the center of the display face.

**Directional Keys** The directional keys are used to navigate through the WI-127's menus. These keys are labeled ESCAPE (up), ENTER (down), ← (left), and MENU (right) and are positioned in a compass-like cluster on the display face. These directional keys are denoted by the small transparent arrows located next to them. ESCAPE, ENTER, and ← also support numeric entry.

- ESCAPE**      Exits a menu parameter without saving any changes.
- ENTER**      Used to end digit entry, accept a change made, or select an item from a function list.
- ←**      Backspaces (deletes the last digit or punctuation mark entered) while in numeric entry and moves left within a menu.
- MENU**      Accesses menus and moves right within a menu.

---

## Annunciators

---

The WI-127 has fourteen annunciators.

- Gross**      Illuminates when indicator is in gross weighing mode.
- Tare**      Illuminates when viewing tare values in the various tare registers.
- Net**      Illuminates when indicator is in net weighing mode.
- lb, kg, other**      Illuminates the active unit of measure in weighing mode.
- Print**      Illuminates when the indicator is transmitting data.
- Zero**      Illuminates when the scale is within the configured center of zero.
- Motion**      Illuminates when the scale detects motion (within configured motion window).
- Under, Accept, Over, Cutoff, ID**      Specific application annunciators.

## Gross Weighing



### Attention

*The socket-outlet must be installed near the equipment and easily accessible.*

To perform gross weighing operations, follow these steps:

1. Power up the indicator. Indicator powers up in gross weighing mode.
2. Verify the scale is empty and zero the scale by pressing the **ZERO** key. Zero weight is displayed and the zero annunciator illuminates.
3. Select unit of measure by pressing the **UNITS** button. The units annunciator will illuminate next to the chosen unit of measure.
4. Place weight on the scale. Gross weight is displayed.

## Net Weighing

For net weighing operations a tare needs to be entered. A tare can be entered by three methods: using the pushbutton tare, using quick keypad tare entry, or selecting a tare from the tare register (a memory bank of up to ten tares).

### Pushbutton Tare

1. With the scale empty and the indicator in gross weighing mode, zero the scale by pressing the **ZERO** key. Zero weight is displayed and the zero annunciator illuminates.
2. Place the weight to be tared on the scale. The weight of the object is displayed.
3. Press the **TARE** key on the indicator. The weight is tared, the display reads zero and the net annunciator illuminates.
4. Add more weight to the scale. Net weight is displayed.
5. View the gross weight by pressing the **SELECT** button. . . Gross weight is displayed and the gross annunciator illuminates.
6. Press the **SELECT** key again to see the tare value. . . Tare value is displayed and the tare annunciator illuminates.
7. Press the **SELECT** key again to see the net value. Net weight is displayed and the net annunciator illuminates.

*You may view the current or active tare value at any time during a weighing process. From gross or net weighing mode, press **SELECT** until the tare annunciator illuminates. If a tare value is in use, it will be displayed.*



## Quick Keypad Tare Entry

1. From display mode, enter a tare value using the numeric keys 0-9. . . Entered value is displayed.
2. Push **TARE**. . . Tare value is accepted, net weight is displayed, and the net annunciator illuminates.

## Selecting a Tare Register

Tare values must be entered in the tare registers before they can be used in weighing operations. Refer to the section “Entering and/or Changing Values in Tare Registers” on the following page.

There are two ways to select a tare register:

#1:

- a. From display mode, press **F1**. Tare mode is displayed and the tare annunciator illuminates.
- b. Scroll through the tare registers by pressing the **MENU** (forward) and **←** (backward) keys, or by repeatedly pressing **F1**. The tare registers are in the order listed here: General register → Register #1 → #2 → #3 → #4 → #5 → #6 → #7 → #8 → #9 → #0. Stop when the register you wish to use is displayed. (For this example, tare register #3 will be used.)  
**3 0** is displayed, indicating that register #3 has no value entered. (Your indicator may have a value in register #3.)
- c. Press **ENTER** to select the displayed tare register. . . Indicator returns to display mode.

or

#2:

- a. From display mode, key in the number of the tare register you wish to use. . . Tare register number is displayed.
- b. Press **F1**. . . That tare register is selected and indicator returns to weigh mode.

## Entering and/or Changing Values in Tare Registers

To exit back to normal weighing mode, press the **SELECT** key and save changes as needed by pressing **ENTER** with **SAVE?** displayed.

1. From display mode, press **F1**.
2. Scroll through the tare registers by pressing the **MENU** (forward) and **←** (backward) keys, or by repeatedly pressing **F1**.
3. You can enter/change a tare value in a register in two ways:

- 3A. **Key in a tare value:**  
With the desired register number displayed, key in **155** for this example, then press **ENTER**. . .

Tare mode is displayed and the tare annunciator illuminates.

The value is accepted and displayed in net mode.

or

- 3B. **Use the pushbutton tare:**  
With the desired register number displayed and the tare weight on the scale, press **TARE**.

The register number and new tare weight are displayed and the tare annunciator illuminates.

4. Press **MENU** to proceed to the next tare register.
5. Press **ENTER** or **SELECT** to accept the displayed tare and return to the display mode.

## Clearing the Active Tare

There are two ways to remove the current or active tare weight.

- A. Remove all weight from the scale and press **TARE**. . .

Tare register is cleared and display returns to gross mode.

- B. From any weight display mode, press **0**, then press **TARE**. . .

Tare is cleared and display returns to gross mode.

## Net Weighing Operation

1. After a tare is established, place the indicator in net mode by pressing the **SELECT** key until. . .
2. Place material to be weighed in the tared container on the scale.

Net annunciator illuminates. Zero weight will be displayed with the container on the scale.

Net weight of material is displayed.

# Using Cutoff Registers

## Viewing cutoffs

Press **ENTER** at any time to exit the cutoff register menu.

The standard WI-127 includes up to three cutoffs. Adding the optional cutoff card raises this number to ten.

When activated (weight on the scale is less than the weight in the cutoff registers), these cutoffs are all on at the same time. Each cutoff will deactivate as soon as the weight on the scale matches the value in each cutoff register.

Cutoffs may be positive or negative values.

Cutoff registers may be viewed by two methods:

Method A:

1. Press the **F3** key. . . 1 xx is displayed. The number 1 stands for cutoff register #1 and xx is the current value in register 1.
2. Continue pressing **F3** or **MENU** to scroll forward or **←** to scroll backward through the remaining cutoff registers.

Method B:

If you know which cutoff register you wish to view, press the number of that register, then press **F3**. That particular cutoff register is displayed. You may scroll through the remaining registers by pressing the **F3** key consecutively.

## Entering cutoff values

Press **ENTER** at any time to exit the cutoff register menu.

To enter a cutoff value,

1. Press **F3** until the cutoff register you wish to set is displayed. . . 3 0 (for example).
2. Enter the cutoff value in one of two ways:
  - 2A. Key in the correct cutoff value using the keypad . . . 3 xx is displayed.
  - or
  - 2B. With active weight on the scale, press **TARE** . . . The active weight is set as the cutoff value.
3. Press **MENU** or **F3** to accept the value and move to the next cutoff register.

## Deactivating/clearing cutoff values

To deactivate or clear a cutoff value, set the value to zero.

# Checkweighing

## Setting Target and Over/Under Values

The WI-127 is configured to perform checkweighing functions. The checkweighing parameters are accessed through the Operations Menu shown in Figure 2.

The target value must be considered when determining values to enter for over and under. Depending on the target values, the over/under values can be entered as either actual weight values or as tolerance values.

If the target value is zero, you may enter over and under values as actual weight. For example, if the **target** = 0, **over** might = 100 lbs, and **under** might = 50 lbs. This means that any weight between 50 lbs and 100 lbs is acceptable. (Note: The *ACCEPT* annunciator does not illuminate when target = 0.)

If the target value is a value other than zero, the over and under values must be set as tolerances. For example, if **target** = 100, **over** might = 10, and **under** might = -10. This means that any weight between 90 and 110 lbs is acceptable.

1. Press **MENU** until. . . **OVER** is displayed.
2. Press **ENTER**. . . The over tolerance is displayed and the *OVER* annunciator illuminates.
3. Using the keypad, enter the new over tolerance value. . . New value is displayed.
4. Press **ENTER**. . . **OVER** is displayed.
5. Press **MENU**. . . **UndEr** is displayed.
6. Press **ENTER**. . . The under tolerance is displayed and the *UNDER* annunciator illuminates.
7. Enter the new under tolerance value. . . New value is displayed.
8. Press **ENTER**. . . **UndEr** is displayed.
9. Press **MENU**. . . **tArgEt** is displayed.
10. Press **ENTER**. . . The target value is displayed and the *ACCEPT* annunciator illuminates.
11. Enter the new target value. . . New value is displayed.
12. Press **ENTER**. . . **tArgEt** is redisplayed.
13. After entering all new values, press **SELECT**. . . Indicator returns to display mode.

## Checkweighing Operation

1. With the indicator in display mode, verify the scale is empty and zero the scale by pressing the **ZERO** key. . . Zero weight is displayed and the zero annunciator illuminates.
2. Select the unit of measure by pressing the **UNITS** button. . . The units annunciator will illuminate next to the chosen unit of measure.
3. Place weight on the scale. . . Weight will be displayed and the **UNDER, ACCEPT** or **OVER** annunciator will illuminate.

## Customizing the Indicator

### Viewing and Editing the ID Number

#### Viewing the ID number

The ID number may be up to 8 digits in length. It may include any combination of the numbers 0 through 9, dashes, and one decimal point.

1. From display mode, press **F2**. . . The current ID number is displayed.
2. After viewing, press **ESCAPE**. . . Indicator returns to display mode.

#### Editing the ID number

1. From display mode, press **F2**. . . The current ID number is displayed.
2. Enter your new ID number using the keypad. If you make a mistake entering the new ID number, use the **←** key to backspace and delete the incorrect digits. . . New ID number is displayed.
3. With your new ID number displayed, press **ENTER**. . . The new ID number is saved and the indicator returns to display mode.
4. You may check the new ID number by pressing **F2**. . . The new ID number is displayed.

*ID number is not included in the default printout. To customize your printout to include this item, refer to your Service Manual.*

## Viewing and Setting Time

*To exit back to normal weighing mode, press the **SELECT** key and save changes as needed by pressing **ENTER** with **SAVE?** displayed.*

*If you enter an incorrect digit, press **←** to clear the display one digit at a time.*

*Time and date are not included in the default printout. To customize your printout to include these items, refer to your Service Manual.*

1. From display mode, press **MENU** once. . . .
2. Press **ENTER**. . .
3. Press **UNITS** to toggle between the 12 hour and 24 hour clocks.
4. **To set the 12 hour clock:**
  - a. Key in the time as **hh mm**.
  - b. Press the **+/-** key to toggle between A.M. & P.M.
  - c. After the correct time is entered, press **ENTER** to accept the new time.**To set the 24 hour clock:**
  - a. Key in time as **hh mm ss**.
  - b. After the correct time is entered, press **ENTER** to accept the new time.
5. Press **ENTER** to view the new time. . .
6. Press **ESCAPE** to return to display mode. . .

**Hour** is displayed.

The current time is displayed.  
In the 12-hour clock configuration time is displayed as hours, minutes, and **A** for A.M. and **P** for P.M. (e.g. **09 40 A**).

In the 24-hour clock configuration time is displayed as hours, minutes, and seconds (e.g. **09 40 30**).

The new time is displayed.

Indicator returns to display mode.

## Viewing and Setting the Date

*If you enter an incorrect digit, press **←** to clear the display one digit at a time.*

1. From display mode, press **MENU** twice. . .
2. Press **ENTER**. . .
3. To change the date, key in the new date using the numeric keypad (the entire date must be entered), then press **ENTER**. . .
4. Press **ENTER** again to view the new date  
**or**  
Press **ESCAPE** to return to display mode. . .

**dAY** is displayed.

The date is displayed as month-day-year.

The new date is accepted and **dAY** is redisplayed.


Indicator returns to display mode.

## Operations Menu

Your WI-127 is configured to display and edit time, date, over, under and target values in the Operations Menu. These parameters can be viewed and changed if allowed. **This manual assumes the unit is configured to allow full access to these functions.**

To enter the Operations Menu press **MENU**. Use the directional keys to maneuver through this menu:

**ESCAPE** = up  
**ENTER** = down  
**←** = left  
**MENU** = right



**Figure 2**  
Operations Menu

Serial Communication

The WI-127 has a bi-directional serial port with RS-232, RS-485/422 or 20 mA current loop communication capability. Your unit may be customized to print according to your needs. An example of the default print layout is shown below:

G 4500 lb  
2 T 2000 lb  
N 2500 lb

What is transmitted is a label for the displayed weight (**G** for gross, **T** for tare, **N** for net), the tare register number (tare weights only), the actual weight, and the unit of measure.

Error Messages

The following are displays you may see if problems occur or if invalid operations are attempted with your WI-127:

Display	Description
<div>O. LoAd</div>	Overrange weight.
<div>-----</div>	Underrange weight.
<div>- - - - -</div>	Recovering from lock-up or out of range condition.
<div>Loc' up</div>	A-D converter is not functioning.
<div>L.C. Error</div>	A-D converter subjected to an input signal beyond $\pm 5.00000$ mV/
<div>Can't</div>	The unit cannot perform a function. Displayed only while key is held down.
<div>Flashing *</div>	Corrupted data in the reset menus. See the <i>Service Manual</i> . (* = RESET, SETUP, or CAL)
<div>Sealed</div>	Displayed while a key is pressed when attempting to modify a sealed selection without edit privileges.
<div>Auto. 0</div>	Displayed while waiting for a stable, valid weight to use as a zero reference on power-up.
<div>Lo. Volt</div>	Displayed when input voltage to excitation regulator drops below 10.5 VDC. Will clear when input voltage rises above 11.5 VDC.
<div>1 Busy</div>	Displayed when the ready/busy handshake has exceeded its time out limit. Default is 2 seconds. This can also apply to optional 2nd and 3rd serial ports.



# Indicator Diagnostics

## Test Mode

The test mode is used to test various functions of the WI-127. The test menu is shown in Figure 3.


To enter the test menu:

1. Press and hold **ESCAPE** for two seconds. . . **About** is displayed.
2. Press **MENU** two times. . . **tEst** is displayed.
3. Press **ENTER**. . . **diSPLAY** is displayed.

Maneuver through the parameters using the directional keys:

**ESCAPE** = up  
**ENTER** = down  
**←** = left  
**MENU** = right

You may exit to display mode at any time by pressing **SELECT**.



**Figure 3**  
Test Menu

Below are the explanations for the items you see in the test menu.

- Display** — Performs a test of the display segments and LEDs. With **diSPLAY** displayed, press **ENTER** once to initiate an automatic test. Press **ENTER** again to stop the automatic test, or press **←** and **MENU** consecutively to step through the display test manually. Press **ESCAPE** to exit the display test.
- Buttons** — Performs a test of the keypad. With **buttonS** displayed, press **ENTER** and the word **nOnE** will appear on the screen. Press any key except **MENU** to check for proper key functioning. The title of each key will appear on the display as it is pressed. After testing the buttons, press **MENU**.
- A to D** — Performs A-to-D test to check the raw offset and gain of the electronics. With **A to d** displayed, press **ENTER** to view the A-to-D value. The span is 20,000 counts per millivolt per volt. Press **ESCAPE** to return to **A to d**.

<b>Loadcell —</b>	Displays the factory normalized loadcell input. With <b>LOADCELL</b> displayed, press <b>ENTER</b> to view the counts. Press <b>UNITS</b> to toggle between the counts display mode and mV/V display mode. Span is 200,000 counts per millivolt per volt. Press <b>ESCAPE</b> to return to <b>LOADCELL</b> .
<b>Serial —</b>	Allows testing of the internal serial ports. With <b>SERIAL</b> displayed, press <b>ENTER</b> to select the port to test. Port 1 is always the internal serial port. (Port 2 and 3 are only offered if extra serial ports are installed.) Press <b>ENTER</b> again to view ready/busy. Then press <b>MENU</b> to view loop/no loop. Press <b>ESCAPE</b> to return to <b>SERIAL</b> .
<b>Outputs —</b>	Allows testing of the outputs. With <b>OutPutS</b> displayed, press <b>ENTER</b> twice to cycle through the available outputs in sequential order. Press <b>ESCAPE</b> — <b>SEqUEnCE</b> is displayed. Press <b>MENU</b> to view the available outputs. Press <b>ENTER</b> to view the status of the outputs. The outputs are numbered left to right, starting with one. A "1" indicates the output is activated; a "0" indicates the output is deactivated. To change the status of the output, move the decimal point to the right of the output you wish to change. Toggle the status by pressing <b>ENTER</b> . If the optional I/O board is installed, an additional eight outputs are available under <b>Out. 9-16</b> . Press <b>ESCAPE</b> to return to <b>OutPutS</b> .
<b>Inputs —</b>	Allows testing of the inputs. With <b>InPutS</b> displayed, press <b>ENTER</b> — <b>StAndArd</b> is displayed. Press <b>ENTER</b> again to view the status of each input. The inputs are ordered 1-8 from left to right. A "1" indicates the input is activated; a "0" indicates the input is deactivated. If the optional I/O board is installed, an additional eight inputs are available under <b>OPtion</b> . Press <b>ESCAPE</b> twice to return to <b>InPutS</b> .
<b>Voltages —</b>	Allows testing of the power supply voltages. With <b>VoltAGES</b> displayed, press <b>ENTER</b> to test the unregulated loadcell excitation power supply voltage (13 volts). Press <b>MENU</b> repeatedly to scroll through the remaining power voltages: the -5 volt excitation voltage (-5 volts), the unregulated 5 volt logic supply voltage (10 volts), and the relay supply voltage (24 volts). Press <b>ESCAPE</b> to return to <b>VoltAGES</b> .

# In-Motion Option

The WI-127 has an optional software package for use with in-motion weighing applications such as conveyor and monorail scales. This short supplement details the few differences the user will notice in the operation of the WI-127 with this software installed and functioning.

## Display Differences

While weight information is being calculated on an object passing across the scale, the indicator will show middle dashes.

Once the weight has been acquired it is displayed for seven seconds. The ID annunciator lights up while the weight is displayed. This is a change in function for the ID annunciator.

If an error occurs while acquiring a weight the display will show **ERROR** for seven seconds.

## Function Key Differences

The **F1** key is a **TARE** key.

The **F2** key accesses the Over, Under, and Target setup.


The **F3** key is for entering cutoff values.

## Menu Differences

The Operation Menu in Figure 2 of this manual changes as follows and now looks like Figure 4:

ID was added.

Over, Under, and Target, were moved to the F2 key.



**Figure 4**  
In-motion operation menu







# Avery Weigh-Tronix

## Declaration of Conformance to SMA Standard Year of Declaration 2002 Production Meets Type



We the manufacturer of

Model	Type	Certificate and Number	Issued by
WI-127	Electronic Indicator	NTEP CC 96-140A1	NCWM

Declare in our responsibility the conformance of the above listed models and types to the mentioned certificates and the requirements of the SMA standard.

This declaration becomes valid when the SMA Conformance Logo, having our name or trademark is applied to the device or its accompanying documentation.

\* SMA PRODUCTION MEETS TYPE DEVICE MANUFACTURER Conformance Logo and Design are a registered trademark of the Scale Manufacturers Association

# Avery Weigh-Tronix



**Avery Weigh-Tronix**  
1000 Armstrong Dr.  
Fairmont, MN 56031 USA  
Telephone: 507-238-4461  
Facsimile: 507-238-4195  
e-mail: [industrial@weigh-tronix.com](mailto:industrial@weigh-tronix.com)  
[www.wtxweb.com](http://www.wtxweb.com)

**Avery Weigh-Tronix Canada, ULC**  
217 Brunswick Boulevard  
Pointe Claire, QC H9R 4R7 Canada  
Telephone: 514-695-0380  
Toll free: 800-561-9461  
Facsimile: 514-695-6820  
[www.weigh-tronix.ca](http://www.weigh-tronix.ca)